

LEXUS UX
VEHICLE IDENTIFICATION NUMBER CODING SYSTEM

Constitution

*: Described in each section below

Section	1	2	3	4			
	*	*	Check Digit	Model Year	*	Serial Number	
	1 2 3	4 5 6 7 8	9	10	11	12 13 14 15 16 17	

Section 1: Geographic Area & Country, Manufacturer, and Type of Vehicle

1st - 3rd Digits	Code	Geographic Area & Country	Manufacturer	Type
	JTH	Asia, Japan	Toyota Motor Corporation	Passenger Car

Section 2: Vehicle Description Section

		Code	Description	
4th Digit	Body Type	Y	5Door Wagon, Two-Wheel Drive	
		U	5Door Wagon, Four-Wheel Drive	
5th Digit	Engine Type	3	M20A-FKS	GASOLINE, PORT+DIRECT, L4, 2L, 169HP
		6	M20A-FXS, 3NM	GASOLINE(HYBRID), PORT+DIRECT, L4, 2L, TBA
		9	M20A-FXS, 3NM,1MM	GASOLINE(HYBRID), PORT+DIRECT, L4, 2L, TBA
6th Digit	Restraint Devices & their Locations	J	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Curtain Shield Air Bag: All rows Side Air Bag: All rows Knee Air Bag: Driver & Passenger seats	
7th Digit	Series	B	MZAA10L MZAH10L MZAH15L	
8th Digit	Line & Make	H	LEXUS UX	

Section 4: Vehicle Plant of Manufacture

		Code	Description
11th Digit	Plant of Manufacture	2	Toyota Motor Kyushu, Inc.