

**TOYOTA C-HR**  
**VEHICLE IDENTIFICATION NUMBER CODING SYSTEM**

## Constitution

\*: Described in each section below

Section	1	2	3	4			
	*	*	Check Digit	Model Year	*	Serial Number	
	1 2 3	4 5 6 7 8	9	10	11	12 13 14 15 16 17	

Section 1: Geographic Area & Country, Manufacturer, and Type of Vehicle

	Code	Geographic Area & Country	Manufacturer	Type
1st - 3rd Digits	NMT	Europe, Turkey	Toyota Motor Manufacturing, Turkey, Inc.	Passenger Car
	JTN	Asia, Japan	Toyota Motor Corporation	Passenger Car

Section 2: Vehicle Description Section

		Code	Description
4th Digit	Body Type	K	5Door Sedan, Two-Wheel Drive
5th Digit	Engine Type	H	3ZR-FAE GASOLINE, PORT, L4, 2L, 145HP
6th Digit	Restraint Devices & their Locations	M	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Curtain Shield Air Bag: All Rows Side Airbag: All Rows Knee Air Bag: Driver seat only Cushion Air Bag: Passenger seat only
7th Digit	Series	B	ZGX10L
8th Digit	Line & Make	X	TOYOTA C-HR

Section 4: Vehicle Plant of Manufacture

		Code	Description
11th Digit	Plant of Manufacture	1	Iwate Plant, Toyota Motor East Japan, Inc.
		R	Toyota Motor Manufacturing, Turkey, Inc.